



# Role of Interfacial Crystallization in Understanding Structure-Property Relationships in Polyolefin Blends

Jennifer Hannah

Advisors: Alex Jordan, Chris Macosko




## Objective:

Determine how the processing method affects blend architecture and mechanical properties of polyethylene/polypropylene blends.

## Introduction:

- Polyethylene (PE) and polypropylene (PP) are the two highest volume produced polymers in the world<sup>1</sup>.
- Despite being chemically very similar hydrocarbons, PE and PP are immiscible and experience low interfacial adhesion<sup>2,3</sup>, limiting recycling and other practical applications of the mixture of polymers.
- Catalyst selection, impacting the polymer chain distribution, could improve the interfacial adhesion between these polymers<sup>4</sup>.
- PP/PE adhesion increases by 20-fold<sup>4</sup> when Ziegler-Natta catalyzed polymers are replaced with metallocene catalyzed polymers.
- It may be possible to increase interfacial area by creating micron scale droplets in blended samples of the polymers.

## Materials:



## Blend Preparation:

- Extruded blend sheets and compression molded blends were prepared
- Extruded blends prepared by twin screw extrusion
  - Kneading blocks and forward conveying elements mix the materials
  - Specified ratios: 0, 25, 50, 75, 100 % PE
- Extruded sheets were also pelletized for further processing
- Compression molded blends were prepared
- Blended pellets were placed in molds and hot pressed for 5 minutes at 180 °C



Prism Twin Screw Extruder




Prism Pelletizer




Carver Hot Press

**Morphology:** Samples were cryo-microtomed and etched to remove polypropylene before imaging

## Extruded Blend Sheets – Imaging



## Compression Molded Blends – Imaging



- Droplet-matrix morphology was observed at PE<sub>75</sub>/PP<sub>25</sub> and PE<sub>25</sub>/PP<sub>75</sub> offset compositions
- Spherical droplets were observed in compression molded samples
- Larger droplet size of R<sub>avg</sub>=5.04 μm in zhE/ziP blend compared to 0.96 μm in miE/miP and 1.47 μm in mhE/miP


## Methods: Tensile Testing

- PE/PP blend samples were molded or cut into a dog bone shape to increase grip and reduce slipping.
- Shimadzu AGS-X tensile tester was used to apply a strain at a rate of 5mm/minute, stress on the sample was recorded.


Dog bone Sample




Shimadzu AGS-X



## Extruded Blend Sheets – Tensile Data



## Compression Molded Blends – Tensile Data



## Conclusion:

- Extension is greater with extruded blend sheets when compared to compression molded blends.
- This is likely due to the elongated, rod-like droplets that formed during the processing of the extruded samples.
- The spherical droplets that formed in the compression molded blends corresponded to lower sample extension during tensile testing.
- Compatibilized miE/miP pair showed much larger extension than zhE/ziP and mhE/miP pair.
- The improved mechanical properties of the extruded blends suggest an avenue to recycle mixtures of PE/PP without separating the two polymers.

## Acknowledgements:

Imaging by Kyungtae Kim  
This project was supported by the University of Minnesota's Undergraduate Research Opportunities Program.

## References:

- 1F. Galie, *ICIS* **2016**.
- 2F.S. Bates, M.F. Schulz, J. H. Rosedale, K. Almdal, *Macromolecules* **1992**, 25 (20), 5547-5550.
- 3G.H. Fredrickson, A.J. Liu, F.S. Bates, *Macromolecules* **1994**, 27 (9), 2503-2511.
- 4K.A. Chaffin, J.S. Knutsen, P. Brant, F.S. Bates, *Science* **2000**, 288 (5474), 2187-2190.